

Tayyor bir komponentli material – tabiiy eski ko‘rinishdagi fakturalar yaratish uchun. Bir vaqtda ikki-uch rang bilan ishlash mumkin.

SIRTNİ TAYYORLASH

Asos toza, qurigan va mustahkam bo‘lishi kerak.

- + Grunt Primer-ni silliqlangan, changlaydigan yoki singdiruvchi yuzalarga surting. Oldin bo‘yalgan devorlar, MDF, DSP, DSPF uchun Grunt Kroyushiy ishlating. Hajmli dekorativ qoplamalar uchun Kvarc Grunt qatlamini qo‘llang.
- + Rang asosini surting: bir qatlam Dekorativ Bo‘yoq, kelajak qoplamaning rangiga kolerlangan.
- + Alchido-ni mikser bilan past aylanishda yaxshilab aralashtiring.

 **Materialni suv bilan suyultirmang.**

SURTISH

BIR RANGLI KLASSIK SURTISH



1-QADAM

Кельма yoki keng шпатель bilan devorning butun yuzasiga birinchi qatlamni tekis va birxil surting. Sdir texnikasi bilan, birxil surish bilan. Quruqlanish kamida 8 soat. Shliflash shart emas.

2-QADAM

Spateldan кельмага oz miqdorda Alchido oling. Qisqa harakatlar bilan mazoklar qiling, chetlarini tekis qoldirmang, effekt aniq bo‘lsin. Mazoklarning ritmi va yo‘nalishi xatolikli bo‘lishi kerak. Barcha devorni birxil to‘ldiring. Quruqlanish 6-8 soat.

3-QADAM

Qatlamni oldingi qadam kabi takrorlang.

 **To‘liq qurish – 24 soat.**

KO'P RANGLI SURTISH



1-QADAM

Кельма yoki keng шпатель bilan birinchi (asosiy) qatlamni devorning butun yuzasiga tekis va birxil surting. Sdir texnikasi bilan, birxil suring.

Quruqlanish kamida 8 soat.

2-QADAM

Ikkinchi va uchinchi qatlamlarni olish texnikasida кельма orqali spateldan navbat bilan ikki yoki uch rang oling, namunadagi retsept bo'yicha. Tonlarga yaqin ranglarni tanlang, yuqori kontrastdan qoching. Qatlamni to'ldirganda dog'lar bo'lmasligi va faktura naqshi uyg'un bo'lishiga e'tibor bering. Oxirgi qatlam odatda birinchi bir rangli qatlamga mos keladi. Qatlamlar va ranglar soni retseptga bog'liq.



To'liq qurish – 24 soat.

HIMOYA

Fakturani kuchaytirish va engil himoya uchun, qatlamga Glezal Fransuzskaya va bo'yoqdan tonli qatlam surish mumkin. Qo'shimcha himoya uchun har qanday suv asosli, bir komponentli yoki ikki komponentli lak ishlatish mumkin.

Lakni oxirgi qatlamdan 48 soatdan keyin surish tavsiya etiladi.